




USER MANUAL

ET XTREME

WITH PATENTED TECHNOLOGY



For Serial Numbers:
H230 XX X XXX
H430 XX X XXX



ORIGINAL INSTRUCTIONS

This manual was originally written in English. All translations are derived from the English version, which shall be considered the authoritative reference.

USER NOTES



For all IPG product manuals please visit www.itape.com/systems-manual or use this QR code

TABLE OF CONTENTS

Technical Assistance	4
Replacement Parts	4
Field Service Assistance	5
Warranty Information	6
General Information	7
Description of the ET xtreme Tape Head	7
Definitions	7
Important Safeguards	8
Label Placement	9
Safety Label Descriptions	10
Machine Nameplate	11
Important Safeguards	12
Explanation of Signal Word Consequences	12
Operator Skill Level Descriptions	13
Specifications	14
ET xtreme Dimensions	14
Machine Components	15
Operating Speed	16
Tape Specifications	16
Operating Conditions	16
Carton Specifications	16
Set-up Procedure	17
Receiving and Handling	17
Ordered With IPG Case Sealers	17
Ordered Separately	17
Set up	17
Tape Loading	18
Tape Threading Diagram	19
Adjustments	20
Changing the Front Tape Leg Lengths	20
Changing the Rear Tape Leg Lengths	20
Clutch Roller Adjustment	21
Low Profile Setting	21
Main Spring Adjustment	22
Knife Arm Spring Adjustment	23
Tape Mandrel Adjustments	24
Preventative Maintenance	25
Lubrication:	25
Cleaning:	25
Blade Guard Oiler Pad	26
Cleaning and Changing the Blade	26
Cleaning and Changing the Front Application Roller	27
Cleaning and Changing the Rear Application Roller	28
Replacing the Dual Independent Wiping Tabs	29
Replacing the Blade Guard and Guard Torsion Spring	30
Replacing the Knife Guard Spring	31
Cleaning the Tape Path	32
Cleaning the Clutch Roller Assembly	32
Replacing Mandrel Sprags	33
Recommended Spare Parts	34
Troubleshooting	35
Appendix B	38
Parts Listing	38

TECHNICAL ASSISTANCE

This is the Interpack Model **ET xtreme** Tape Head you ordered. It has been set up and tested in our factory with IPG manufactured Pressure Sensitive Tape. If any problems occur when setting up or operating this equipment, please contact the authorized distributor from where you purchased this item.

If contact with the authorized distributor is not possible, **IPG Machinery Support** is available. Should the need to contact **IPG Machinery Support** arise, **please have the equipment model and serial number available prior to contact**. This information can be found on the nameplate of the tape head as well as on the machine, both sets of information may be necessary to assist. A section at the bottom of this page is available to write this information down. **IPG Machinery Support** is available during normal business hours (M-F 8am-7pm) Eastern Time.

Phone: 813-345-3070

Email: machsupp@itape.com

Replacement Parts

A breakdown of parts, including part numbers, can be found in the appendix of this manual. If you know the part number that you require please contact your authorized distributor or IPG Customer Service 877-447-4832 Option 3

Please use this area to enter the detailed information on your Case Sealer and Tape Heads. This should be filled out at the time of install. This information can be found on the nameplate of the machine, typically on the side the operator controls are on. On the WAT Tape Heads serial information can be found near the air intake of the head. Additional **ET xtreme** tape heads can be obtained through an IPG leasing program. Reach out to your local IPG representative for more details.

Machine

Model

Serial

Distributor

Name

Phone/Email

Tape Head Top

Model

Serial

Tape Head Bottom

Model

Serial

Date of Purchase

Date of Install

FIELD SERVICE ASSISTANCE

Your Interpack Case Sealer and Tape Heads are designed to provide years of trouble free operation. This is not without proper preventative maintenance, a recommended schedule can be located in the maintenance section of this manual, performed by then end user of the equipment. If any problems arise with this machine during the normal course of operation, your properly trained and qualified internal service personnel should be able to repair any issues after consulting the troubleshooting section of this manual in conjunction with phone and/or email support from IPG Machinery Support.

Field Service Support is available from your IPG Authorized Distributor at additional cost if the problem cannot be remedied after consulting the troubleshooting section of this manual.

IPG offers comprehensive programs that help keep your equipment up and running.

Proactive maintenance efforts help to prevent equipment failures and costly emergency repairs. Keeping your machine in optimal working condition also enhances employee safety, reduces facility downtime and efficiently allocates internal resources.

Please contact your IPG Representative to discuss the best options for your IPG equipment.

WARRANTY INFORMATION

EQUIPMENT WARRANTY AND LIMITED REMEDY: The following warranty is made in lieu of all other warranties, express or implied, including, but not limited to, the implied warranty of merchantability, the implied warranty of fitness for a particular purpose, and any implied warranty arising out of a course of dealing, a custom or usage of trade:

Intertape sells its Interpack Tape Heads, Case Tapers and Case Erectors with the following warranties:

1. The IPG Pressure Sensitive Tape Heads' knife blades, springs and wipe down rollers will be free from all defects for a period of ninety (90) days.
2. All other IPG Pressure Sensitive Tape Head parts will be free from all defects for one (1) year after delivery.
3. Water Activated Tape Heads' blades will be free from defects for ninety (90) days after delivery.
4. Drive Belts will be free from defects for ninety (90) days after delivery
5. The Gear Motors will be free from defects for one (1) year after delivery.
6. All other components for Case Tapers and Case Erectors will be free from defects for one (1) year after delivery.

If any part is proven defective within its warranty period, then the exclusive remedy and Intertape's and the seller's sole obligation shall be, at Intertape's option, to repair or replace the part, provided the defective part is returned immediately to Intertape's factory or an authorized service station designated by Intertape.

A part will be presumed to have become defective after its warranty period unless the part is received or Intertape is notified of the problem no later than five (5) calendar days after the warranty period.

If Intertape is unable to repair or replace the part within a reasonable time, then Intertape, at its option, will replace the equipment or refund the purchase price. Intertape shall have no obligation to install the repaired or replacement part.

Intertape shall have no obligation to provide or pay for the labor required to install the repaired or replacement part.

Intertape shall have no obligation to repair or replace (1) those parts failing due to: operator misuse, carelessness, or due to any accidental cause other than equipment failure, or (2) parts

1. Failure or damage is due to misapplication, lack of proper maintenance, abuse, improper installation or abnormal conditions such as temperature, moisture, dirt or corrosive matter, etc.
2. Failure due to inadequate cleaning, improper operating environment, improper utilities or operator error.
3. Failure due to operations above the rated capacities, or in any other improper manner, either intentional or otherwise.
4. Failure is due to equipment, which has been altered by anyone other than an authorized representative of Intertape Polymer Group.
5. Failure is due to an attempt by the purchaser to correct alleged defective equipment. In this event the purchaser is responsible for all expenses incurred.

LIMITATION OF LIABILITY: Intertape and seller shall not be liable for direct, indirect, special, incidental or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability or any other legal theory.

The foregoing Equipment Warranty and Limited Remedy and Limitation of Liability may be changed only by written agreement signed by authorized officers of Intertape and seller.

GENERAL INFORMATION

Description of the ET xtreme Tape Head

This tape head is designed to provide years of trouble free operation. If any problems arise with this machine during the normal course of operation, your properly trained and qualified internal service personnel should be able to repair any issues after consulting the [Troubleshooting](#) section of this manual.

The **ET xtreme** Tape Head is designed to apply IPG brand pressure sensitive tape (PST) to the center seam of regular slotted corrugated cartons. The **ET xtreme** Tape Head can be adapted into a variety of manufactured case sealers.




Figure 1: ET xtreme

Definitions

Common terms that will be used throughout this manual.

Tape Head – This will refer to the ET xtreme tape head for the remainder of this manual

Case Sealer – Refers to IPG manufactured Case Sealers

Machine System – Refers to the fully assembled Case Sealer with the Tape Head(s) installed

User/Operator – The individual who has been trained on the daily use of the Machine System

Maintenance Champion – The individual(s) who work for the end user of the Machine System who are responsible for conducting general and preventative maintenance

IMPORTANT SAFEGUARDS

There are a number of safety labels used on the **ET xtreme** Case Sealer. These labels are placed at different locations on the machine to warn operators and service personnel of possible dangers (refer to Figure 3). Please read the labels on the machine and the following safety precautions before using the machine.

Read this manual for other important safety operating and service information.

Only trained personnel are to operate machine.

Only fully qualified technicians are to service this machine.

Wear safety glasses.

Shut off power to machine before adjusting machine or loading & threading Tape Heads.

Disconnect electrical power and compressed air (where applicable) before servicing.

Follow Lock Out / Tag Out Procedures BEFORE servicing any machinery.

All factory installed covers and guards must be in place before operating.

Stay clear of moving parts which can shear and cut.

Should any of the safety labels on the Case Sealer be damaged or destroyed, replacements can be ordered through your distributor.

LABEL PLACEMENT




Figure 2: Label Placement

SAFETY LABEL DESCRIPTIONS

The labels shown is affixed to the upper rear of the tape head on the serial plate side.

It warns operators and service personnel of the presence of the moving components.

Replacement number: UPM3819



Figure 3: Moving Parts Warning

The labels shown is affixed to center of tape head on the larger of the two split side plate frames.

It is the Interpack nameplate for the HSD ET xtreme line of tape heads.

Replacement number: UPH8174




Figure 4: Serial Label

The label shown is affixed to the knife guard.

It warns operators and service personnel of a sharp hazard from the blade.


Replacement number: UPM2010



Figure 5: Blade Warning Label

Should any of the safety labels on the Case Sealer be damaged or destroyed, replacements can be ordered through your distributor.

MACHINE NAMEPLATE



ET xtreme
Standard Tape Head




Serial Number

Serial Number: H230 25A 000

Manufacturer Details


ipg intertape polymer group®
Machinery Technical Support Options
to Better Serve You:
Toll-free (877) 447-4832 • Direct (813) 345-3070
Email: machsupp@itape.com
An Interpack™ Design Manufactured in Taiwan



Tape Threading Diagram

Figure 6: Label Identification

Reading Interpack Serial Numbers



IMPORTANT SAFEGUARDS

Explanation of Signal Word Consequences



WARNING: INDICATES A POTENTIALLY HAZARDOUS SITUATION, WHICH IF NOT AVOIDED COULD RESULT IN DEATH OR SERIOUS INJURY OR PROPERTY DAMAGE



CAUTION: INDICATES A POTENTIALLY HAZARDOUS SITUATION, WHICH IF NOT AVOIDED COULD RESULT IN MINOR OR MODERATE INJURY OR PROPERTY DAMAGE



WARNING

- 1. To reduce the risk associated with mechanical, pneumatic, and electrical hazards:**
 - Read, understand, and follow all safety and operating instructions before operating or servicing the Case Sealer and/or Tape Head(s)
 - Allow only properly trained and qualified personnel to operate and service this equipment
- 2. To reduce the risk associated with pinches, entanglement, and hazardous voltage:**
 - Turn electrical supply off and disconnect before performing any adjustments, maintenance, or servicing the Case Sealer or Tape Head
- 3. To reduce the risk associated with pinches and entanglement hazards:**
 - Do not leave the Case Sealer running while unattended
 - Turn the Case Sealer off when not in use
 - Never attempt to work on any part of the Case Sealer, Tape Head, load tape, or remove jammed boxes from the Case Sealer while the machine is running
- 4. To reduce the risk associated with hazardous voltage**
 - Position electrical cord away from foot traffic and vehicle traffic
 - Do not operate the Case Sealer with a damaged power cord
- 5. To reduce the risk associated with sharp blades hazards:**
 - Keep hand and fingers away from the tape cutoff blades, the blades are very sharp
- 6. To reduce the risk associated with fire and explosion hazards:**
 - Do not operate this equipment in potentially flammable and/or explosive environments
- 7. To reduce the risk associated with muscle strain:**
 - Use the appropriate rigging and material handling equipment when lifting or repositioning this equipment
 - Use proper body mechanics when removing or installing Tape Heads that are moderately heavy or may be considered awkward to lift
- 8. To reduce the risk associated with mechanical, pneumatic, and electrical hazards:**
 - Allow only properly trained and qualified personnel to operate and service this equipment



CAUTION

- 1. To reduce the risk associated with pinch hazards:**
 - Keep hands clear of the upper head support assembly as boxes are transported through the Case Sealer
 - Keep hands, hair, loose clothing, and jewelry away from box compression rollers, moving belts, and Tape Heads
 - Always feed boxes into the Case Sealer by pushing only from the end of the box

IMPORTANT SAFEGUARDS

Operator Skill Level Descriptions

These descriptions and levels are uniform across all IPG Case Sealers

Skill “A” Machine Operator

This operator is trained to use the Case Sealer with the machine controls, to feed cases into the machine, make adjustments for different case sizes (RSA series machines), to change tape, to start, stop, and restart production, and to clear jams and perform basic troubleshooting.

Important: The end user area supervisor must ensure that the operator has been properly trained on all machine functions before operating the machine.

Skill “B” Mechanical Maintenance Technician

Also referred to as the Maintenance Champion, this technician, is trained to use the Case Sealer as the Operator is able and in addition is able to work with the safety protection disconnected to check and adjust mechanical components, to perform maintenance operations and repair the Case Sealer. A skill “B” operator is not allowed to work on live electrical components.

Skill “C” Electrical Maintenance Technician

This technician is trained to use the Case Sealer as the Operator is able and in addition is able to work with the safety protection disconnected, to check and adjust mechanical components, to perform maintenance operations and repair the Case Sealer. A skill “C” operator is allowed to work on live electrical panels, terminal blocks, and control equipment.

Skill “D” Manufacturer Technician

Skilled technician sent by the manufacturer or its agent (distributors) to perform complex repairs of modifications, when agreed with the customer.

Operators skill level required to perform the following tasks on the Machine System

OPERATION	MACHINE CONDITION	OPERATOR SKILL LEVEL	NUMBER OF OPERATORS
Tape Roll Replacement	Stopped by pressing the Emergency Stop Button	A	1
Blade Replacement	Electrical Power Disconnected	B	1
Ordinary Maintenance and Preventative Maintenance	Electrical Power Disconnected	B	1
Extraordinary Electrical Maintenance	Running with Safety Protections Disabled	C	1
Extraordinary Mechanical Maintenance	Running with Safety Protections Disabled	D	1
Drive Belt Replacement	Electrical Power Disconnected	B	1
Machine Installation & Set-Up	Running with Safety Protections Disabled	B & D	2

Proper Electrical Disconnect is achieved when the machine is unplugged from the electrical socket.

SPECIFICATIONS

ET xtreme Dimensions

2 in. Tape Head Weight: 9 lbs. (4kg)
3 in. Tape Head Weight: 9.9 lbs. (4.5 kg)




Figure 7: Dimensions

SPECIFICATIONS

Machine Components




Figure 8: Components

SPECIFICATIONS

Operating Speed

The ET xtreme can operate as expected in case sealers with belt speeds up to 140 ft/min (42.6 m/min).

Tape Specifications

Use only **IPG Brand Pressure Sensitive Tape**. The ET xtreme can accommodate tape widths of 2in. (50mm) on H230 models or 3 in. (75mm) on H430 models.

A maximum tape roll diameter of 16 in. (405mm) on a 3 in. (75mm) core can be installed on the tape heads.

The standard tape leg length of 2 ¾ in. (70mm) is factory set. The standard tape leg length may vary up to ¼ in. (6mm) based on tape tension and line speed.

The standard tape leg length is adjustable via adjustments to the clutch roller mechanism for the front tape leg and adjustments to the knife arms for the rear tape leg. Adjustments can be made with lengths between 2 and 3 inches (50-75mm).

Operating Conditions

Use in a dry, relatively clean environment at 40° to 105° F (5° to 40° C) with clean dry cartons. Maximum sound pressure level is less than 70dBA.



CAUTION: ET XTREME SHOULD NOT BE WASHED DOWN OR SUBJECTED TO CONDITIONS CAUSING CONDENSATION ON COMPONENTS. FOLLOW CLEANING INSTRUCTIONS.

Carton Specifications

Type

- Regular Slotted Containers (RSC)
- Other styles may be processed. Consult factory.

Material

- 125 to 175 PSI bursting test, single or double wall, B or C flutes
- Other styles may be processed. Consult factory.

Weight

- 0 to 38.5 kg (0 to 85 lbs.) Max

SET-UP PROCEDURE

Receiving and Handling

Depending on how it was ordered the Interpack **ET xtreme** is shipped to the customer preinstalled in IPG equipment or shipped in its own box. The sequence below is step by step instructions to remove all packing materials.

PRIOR TO SIGNING FOR THE TAPE HEAD INSPECT IT FOR ANY DAMAGE THAT MAY HAVE OCCURRED DURING SHIPPING

Do not pick up or hold the tape head from the peel off arm. *EHSR 1.1.5, 1.3.7*

Do not pick up or hold the tape head from the bottom edges of the frame. *EHSR 1.1.5, 1.3.7*

Do not pick up or hold the tape head from any moving or rotating element of the tape head. *EHSR 1.1.5, 1.3.7*

When moving or handling the tape head only grip from the mandrel arm or support cross shafts.

Ordered With IPG Case Sealers

IPG Case Sealers come standard with ET xtreme tape heads installed. These will already have the mounting adapters and main springs installed.

Ordered Separately

When ordered on their own ET xtreme tape heads will ship in a box with assorted adapters, springs, and any other ordered components will be included.

Set up

ET xtreme tape heads have been set up in the factory to run the top 90 percentile of tapes that IPG offers with optimal tape leg lengths preset. These should not need to be adjusted at the time of install.

ET xtreme tape heads are designed to install into a variety of case sealers. This require mounting adapters before being installed into a case sealer. These adapters range from various length hex spacers, bars, and pins. Your tape head should be shipped with everything needed to install it into your case sealer. If anything else is needed contact your Authorized IPG Representative. See the next section to better understand mounting adapters.

Installation Requirements

When ET 2Plus tape heads are being installed into case sealers or case erectors that were not originally manufactured by IPG the integrator must:

- Verify the tape head is mounted in a secured fashion where it will not become dislodged in the course of normal operation. *EHSR 1.1.5, 1.3.3, 1.5.4*
- Verify the tape head is mounted in a manner that eliminates any shear hazards posed by moving components from either the tape head itself or from material interacting with the tape head. *EHSR 1.1.5, 1.3.7*
- Verify the tape head is grounded to the host case sealer or case erector it is being installed into. *EHSR 1.5.2*
- Verify the tape head location and removal and replacement of materials follows all best practices in ergonomic principals. *EHSR 1.1.5, 1.3.1, 1.3.3*
- Verify the tape head's mounting method will not wear and cause the tape head to become dislodged from the host case sealer or case erector. *EHSR 1.3.2*
- Verify the tape head has not been modified and installation corresponds with all IPG instructions on proper mounting. Only the use of IPG provided hardware and materials is allowed.
- Verify the tape head is mounted using only the provided mounting points as identified in the Adapter Installation section of this user manual.


SET-UP PROCEDURE

Adapter Installation

Adapters are vital to the proper installation of IPG tape heads into case sealers. When ordered with a machine the tape heads will come pre-installed with adapters already mounted. When ordered on their own tape heads will ship with a standard assortment of adapters. Additional adapters may be included in the event the tape head is being mounted into a case sealer that is not manufactured by IPG. These may include adapter bars depending on the machine.

On ETX tape heads adapters are mounted into 3/8-24 tapped holes in the side frames. There are a pair of lower points and a set of three (3) upper points, two (2) in the rear, one (1) in the front. Most IPG case sealers will use the lower mounting points labeled 1 and 2. The exception being the top and bottom belt drive machines. Their top tape head cavities will require adapters be in the upper locations. On IPG manufactured case sealers adapter points labeled 4 and 5.

In the event the tape head is being installed into a case sealer not manufactured by IPG please consult IPG Machinery Support to verify proper adapters have been received. If adapter bars or other more complex adaptation is required a specific instruction sheet will be provided.



Adapters come in two parts:

1. **A hex or barrel shaft** where one end has an external 3/8-24 thread and a through hole with either a M6 thread or a 1/4-20 thread depending on the needs. All standard adapters are hex with a M6 threaded through hole. A 5/8 wrench or 16mm may be used to tighten or loosen the adapters.
2. **The mounting pin**, typically a M6 or 1/4-20 socket head cap screw depending on the adapter. This may also be a custom milled threaded insert for adapting into machinery that is not manufactured by IPG.

The hex or barrel shaft portion of the adapter is used to center the tape head in the cavity where the mounting pins are used to make contact with the machine and secure the tape head in place. The 3/8-24 end will always screw into the tape head side frame while the mounting pins will always screw into the M6 or 1/4-20 threads on the flat end of the adapter.


Sizing Adapters

These four adapters are included with 2" and the two shortest with the 3" tape heads when they are ordered separately from a case sealer. When selecting the correct adapter for IPG manufactured case sealers 2" tape heads will typically use UPH0265 while 3" tape heads will typically used UPH3881. Some specialty machines may need the other adapters.


These below diagrams are printed at a 1:1 scale to help you identify which is which.




UPH3881
.114" (2.9mm)
M6-1



UPH0256
.425" (10.8mm)
M6-1



UPH3883
.614" (15.6mm)
M6-1




UPH3883
.925" (23.5mm)
M6-1


SET-UP PROCEDURE

Adapters


The below is a list of adapters that are common in various adapter kits. These are 1:1 scale to assist in the identification of the adapters. Descriptions will include the part number, length of adapter (flat to flat), and internal thread pitch.




UPH3616
1.175" (29.8mm)
M6-1




UPH1045
1.05" (26.7mm)
M6-1




UPH3728
.984" (25mm)
M6-1




UPH9233
.883" (22.5mm)
M6-1




UPH3896
.73" (18.5mm)
M6-1




UPH3707
.675" (17.1mm)
M6-1




UPH9145
.67" (17mm)
M6-1




UPH4765
.62" (15.7mm)
M6-1




UPH0285
.612" (15.5mm)
M6-1




UPH1527
.55" (13.97mm)
M6-1




UPH0799
.500" (12.7mm)
M6-1




UPH0974
.432" (11mm)
M6-1




UPH0566
.421" (10.7mm)
M6-1



UPH9074
.421" (10.7mm)
M6-1



UPH9218
.375" (9.5mm)
M6-1



UPH0139
.084" (2.1mm)
M6-1

Adapter Pins


The below is a list of adapter pins that are common in various adapter kits. These are 1:1 scale to assist in the identification of the adapters.



UPH0133



UPH0946



UPH0132

SET-UP PROCEDURE

Installation Requirements

When ET Xtreme tape heads are being installed into case sealers or case erectors that were not originally manufactured by IPG the integrator must:

- Verify the tape head is mounted in a secured fashion where it will not become dislodged in the course of normal operation.
- Verify the tape head is mounted in a manner that eliminates any shear hazards posed by moving components from either the tape head itself or from material interacting with the tape head.
- Verify the tape head is grounded to the host case sealer or case erector it is being installed into.
- Verify the tape head location and removal and replacement of materials follows all best practices in ergonomic principals.
- Verify the tape head's mounting method will not wear and cause the tape head to become dislodged from the host case sealer or case erector.
- Verify the tape head has not been modified and installation corresponds with all IPG instructions on proper mounting. Only the use of IPG provided hardware and materials is allowed.
- Verify the tape head is mounted using only the provided mounting points as identified in the Adapter Installation section of this user manual.

Intended Use

1. The ET Xtreme tape head is intended to only be used in conjunction with a case sealer or case erector.
2. Only IPG Branded Pressure Sensitive Carton Sealing Tape provided by an Authorized IPG Representative is to be used on the ET Xtreme.
3. Only accessories which are intended to be used on the ET Xtreme and provided by an Authorized IPG Representative may be used.

Forseeable Misuse

The following application or acts are not suitable for the tape head and constitute improper use.

1. Do not use outside or in conditions outside of those outlined in the specification section of this user manual.
2. Do not use in potentially explosive environments.
3. Do not use caustic cleaners when performing maintenance. Follow the approved maintenance procedures.
4. Do not hang from the tape head.
5. Do not place objects on or against the tape head.
6. Do not attempt to remove the tape head from any equipment that is under electrical or pneumatic power.
7. Do not attempt to use the tap head as a hand dispenser.

Disclaimer

The intended use of the ET Xtreme tape head is to be installed into a case sealer or case erector and apply a single strip of IPG Branded Pressure Sensitive Carton Sealing Tape down the center seam of a regularly slotted carton. IPG and its authorized representatives are not responsible for any accidents, damages, or errors caused by:

1. Not following the instructions, illustrations, and warnings as described in this user manual.
2. Use of components or adapters which are not supplied by IPG or an authorized representative.
3. Repairs or modifications done by anyone other than an IPG authorized representative or IPG trained service technician.
4. Improper use or alternation to any of the original parts of the tape head.
5. Not keeping the tape head safety covers attached.

SET-UP PROCEDURE

Tape Loading

Loading tape is the same on all versions of the ET xtreme. Model H275 can take tape up to 2 in. (50mm) wide tape rolls, model H775 can take up to 3 in. (72mm) wide rolls. Follow the below instructions to load a new roll of tape onto the ET xtreme.



CAUTION: LOADING TAPE WILL BRING AN OPERATORS HANDS CLOSE TO THE AREA OF THE CUTTING BLADE. ALWAYS ENSURE THE BLADE GUARD IS AGAINST THE BLADE AND NOT DAMAGED.

1. Turn off the case sealer before removing the tape head. Never remove a tape head from a case sealer that is powered on and running.
2. Remove the tape head from the case sealer.
3. Place the tape head on sturdy flat surface with the tape mandrel facing up.
4. Remove the old tape core from the tape mandrel by pressing the red hooked sprag in while pulling the core off.
5. Discard the used tape core.
6. Pull the Peel Off Roller away from the tape head and twist the peel off arm lock.
7. Take a new roll of tape and position it so the peel off direction is counterclockwise.
8. Pull a roughly 18 in. (450mm) length of tape from the roll.
9. Fold it over on itself to assist you in threading the tape.
10. Unlock the Peel Off Roller back so it is held against the tape roll.
11. The tape should pull over the Peel Off Roller and down towards the clutch mechanism. The adhesive side should be facing away from the roll of tape.
12. The tape should go around the back of the knurled clutch roller, the adhesive side should be in contact with the clutch roller.
13. Tape must then wrap around the front of the idle roller then deeper into the head.
14. The tape will need to wrap around the back of the split roller then fed through the tape shoe. The adhesive side will be in contact with the split roller.
15. Pull the tape through the tape head until non-folded tape reaches the front roller.
16. Using scissors cut the tape at the front roller. Never use a blade against the roller.
17. The tape head may now be reinstalled into the case sealer. Follow the instructions in your case sealer manual for the proper procedure.





Figure 9: 3D Tape Path

Tape threading diagrams can be found on the serial label of the tape head and on the next page.

SET-UP PROCEDURE

Tape Threading Diagram



WARNING: THE KNIFE CONTAINED IN THE TAPE HEADS IS EXTREMELY SHARP. USE CAUTION WHEN THREADING THE TAPE OR PERFORMING MAINTENANCE TO AVOID INJURY.

When threading tape the case sealer should be in an Emergency Stopped or off state to prevent any unintentional motion. Use proper lifting practices when handling a tape head with tape installed.

Figure 10: Tape Threading Diagram

ADJUSTMENTS

Changing the Front Tape Leg Lengths

For safe sealing, the tape leg length has been factory set at 2¾ inches (70mm). The tape leg, however, can be lengthened or shortened if desired.

To adjust the front tape leg length loosen the two M6 screws that secure the Clutch Roller Assembly to the back frame plate of the tape head. It is not necessary to remove these screws. Rotate the whole assembly up and toward the rear of the tape head to shorten the tape leg. Rotate the whole assembly down and toward the front of the tape head to lengthen the tape leg. There are five indexing points. The length adjustment is etched into the frame. When the desired location is selected tighten the two M6 screws back down.

Tape legs may vary +/- ¼ in. (6mm) depending on line speed and tape tension.




Figure 11: Front Tape Leg Adjustment

Changing the Rear Tape Leg Lengths

For safe sealing, the tape leg length has been factory set at 2¾ inches (70mm). The tape leg, however, can be lengthened or shortened if desired.

To adjust the rear tape leg length loosen the three M4 screws that secures the Knife Arm Adjuster to the Knife Arm Assembly. Shift the adjuster toward the front of the tape head to shorten the tape leg. Shift the adjuster toward the rear of the tape head to lengthen the tape leg. When the desired location is selected tighten the two M4 screws back down. Match the opposite side adjuster.

Tape legs may vary +/- ¼ in. (6mm) depending on line speed and tape tension.




Figure 12: Rear Tape Leg Adjustment

ADJUSTMENTS

Clutch Roller Adjustment

The one way clutch roller ensures that there is no backwards motion in the tape and help keep tape legs consistent.

Different qualities of tape have different adhesives and release coats. This has an effect on the dispensing peel-off resistance. This means that different tapes may need various clutch tensions. Factory tension is set prior to shipping.

To decrease the clutch roller's tension, turn the M6 Friction Nut at the end of the roller counterclockwise, it requires a 10mm wrench. Small adjustments can result in large tape changes.

It is recommended to consult IPG Machinery Support before tightening the clutch roller. Over tightening can result in stretched tape leading to weakened adhesion, inconsistent tape legs, no tape being applied, and tape breaks. Any tightening should be performed in $\frac{1}{8}$ turn increments or less.

Proper tape threading will have the adhesive side of the tape running against the knurled surface of the clutch roller. The clutch roller can be cleaned with a mild detergent (soap and water). Do not use high pressure water on the clutch roller. Allow to fully dry before reuse.

Do not use a knife or other cutting instrument against the surface of the clutch roller.




Figure 13: Clutch Adjustment

Low Profile Setting

When processing cases with a 4 inch or lower height it may be necessary to set the tape head into low profile mode to avoid collision between the tape head rollers and parts of the case sealer.

To set the tape head into low profile, loosen the M5 screws that secure the Roller Arm Stops. Compress the arms in to allow this stop to move freely. You may want to remove the Main Spring to remove pressure on the arms. A 3/4 inch box wrench or socket may be needed to hold the hex side of the stop to allow for loosening the screw.

Adjust the stop to the desired position and tighten the M5 screw back down using the indexing positions as a guide. There are two stops one on each side of the tape head.

Placing the tape head into low profile may alter tape leg lengths and may require some adjustments.




Figure 14: Low Profile Adjustment

ADJUSTMENTS

Main Spring Adjustment

The main spring retainers are factory-set for common applications. The top tape head needs lighter springs (UPH0910), while the bottom needs heavier springs (UPH1091). ET xtreme tape heads can run up to 90 ft/min (27.4 m/min). The box type and speed determine the best spring setting. The loops of the spring need to go around the spring posts. A spring hook will greatly assist in the install.

Typically, the lighter spring is used for top sealing and the heavier for bottom sealing. Higher speeds may require heavier springs or increased spring force on the rollers. One end of the main spring attaches to a post on the rear wipedown arm, and the other to the tape head's side frame.

Increasing spring force can damage boxes at higher speeds. Adjust roller pressure by moving the spring retainer post forward (increases pressure) or backward (decreases pressure). If the rear tape leg isn't properly wiped down, adjust the torque by moving the spring retainer post on the rear wipedown arm. Move it up and away from the pivot point to increase torque, or down and closer to decrease torque for weaker boxes.

In the event the rear tape leg is not being properly wiped down the torque may need to be adjusted. It can be adjusted by moving the spring retainer post on the rear wipedown arm. Moving the retainer post up and away from the pivot point will increase the amount of torque on the rear wipedown. For some weaker or thinner fluted boxes a reduction in torque may be needed. To decrease the level of torque the retainer post should be moved down and closer to the pivot point.




Figure 15: Main Spring Adjustments

ADJUSTMENTS

Knife Arm Spring Adjustment

The knife arm spring is factory set but may need to be adjusted when case sealer speeds are high. If tape is consistently not being cut or rear tape legs are unexpectedly long the knife arm spring may need adjustment.

Increasing the force on the knife arm will increase the force in which the knife arm returns to its home position and the speed that which the knife blade will cut through the tape. Increasing this tension will also increase the downward force on the top or bottom of the carton and may cause visual indentations.

To increase the force use a 10mm wrench to turn the nut clockwise.

Decreasing the force on the knife arm will decrease the force at which the knife arm returns to its home position and the speed that the knife blade will cut through the tape. Decreasing the force may result in poorly cut or uncut tape.

To Decrease the force use a 10mm wrench to turn the nut counterclockwise.

Over time the knife arm spring may fatigue and need to be tightened.




Figure 16: Knife Arm Spring Adjustment

ADJUSTMENTS

Tape Mandrel Adjustments

The tape mandrel is set by the factory for proper location. Over time some adjustment may be necessary. There are two adjustments that can be made to the tape mandrel, horizontal position for keeping the tape roll centered, and rotational tension.

To alter the horizontal position the interior jam nut on the back side of the tape mandrel will need to be loosened with a 10mm Allen wrench. A flat head screw driver can then be inserted to adjust the position via the mandrel shaft.

Rotating the mandrel shaft clockwise will pull the mandrel closer to the mandrel arm.

Rotating the mandrel shaft counterclockwise will push the mandrel farther from the mandrel arm.

Once the tape roll and tape path is centered tighten the interior jam nut back down to keep the mandrel shaft in position.

To adjust the rotational tension use a 13mm socket and slip it around the lock nut on the mandrel. The sleeve is sized to only allow a 13mm socket access. Tightening this nut will increase tension on the mandrel until it locks and will not rotate. Loosening the nut will allow the mandrel to rotate more freely. Very small adjustments will have large effects. It is recommended to contact IPG Machinery Support before making this adjustment.




Figure 17: Tape Mandrel Adjustments

PREVENTATIVE MAINTENANCE

The ET xtreme Tape Head has been designed and manufactured with the finest components to provide long, trouble-free performance. General preventive maintenance will improve performance and prolong the life of the tape head. Review the illustrations and chart below for information regarding machine maintenance.



WARNING: TURN OFF ELECTRICAL POWER SUPPLY AND PNEUMATIC SUPPLY (WHEN APPLICABLE) BEFORE PERFORMING MAINTENANCE. THE CUT-OFF BLADE IS EXTREMELY SHARP USE CUT RESISTANT GLOVES WHEN REPLACING THE BLADE.

Lubrication:

The only oil or lubrication should be the application of lubricant on the Blade Guard Oiler Pad.

Cleaning:

Cartons produce a sizable amount of dust and paper chips when processed or handled. If this dust is allowed to build up in the tape head, it may cause increased component wear. Remove the accumulated dust with a shop vacuum. Avoid using compressed air to remove the dust as this may cause the dust to penetrate into parts.

The below chart has been designed for the ET xtreme Tape Heads.

Item	Action Required	Material	Frequency		
			Weekly	Monthly	Quarterly
Blade Guard Oiler Pad	Lubricate	Food Safe Mineral Oil	X		
Hardware	Re-tighten any loose hardware, Replace any missing hardware			X	
Cutting Blade	Inspect for Wear		X		
	Clean	Soap and Water	X		
Mandrel Assembly	Check for Wear and Functionality				X
Peel-Off Roller					
Delrin Roller	Verify free spinning, Clean	Soap and Water	X		
Pivot Shaft	Clean any restrictions	Soap and Water	X		
Spring	Check for fatigue and strength				X
Tape Idle Rollers	Disassemble and Clean	Soap and Water		X	
One Way Clutch Roller	Verify correct rotational tension, Clean	Soap and Water		X	
Tape Shoe	Clean	Soap and Water		X	
Front Wipedown Roller	Clean	Soap and Water	X		
Rear Wipedown Roller	Clean	Soap and Water	X		
Main Spring	Check for fatigue and strength				X
Knife Arm Spring	Check for fatigue and strength				X
Blade Guard Spring	Check for fatigue and strength				X
Wipe Down Tabs	Inspect for wear and stiffness				X
Side Frames	Clean	Damp Cloth	X		

PREVENTATIVE MAINTENANCE

Blade Guard Oiler Pad



WARNING: THE KNIFE CONTAINED IN THE TAPE HEADS IS EXTREMELY SHARP. EVEN A DULL BLADE CAN BE SHARP ENOUGH TO CUT. USE OF CUT RESISTANT GLOVES IS REQUIRED.

The blade in the ET xtreme is kept behind a patented (US-10384904-B2) magnetic red plastic knife guard. The blade cover maintains a closed position via a torsion spring.

There is a felt pad attached to the inside of the blade cover. This pad should receive a few drops of oil once per week. If the tape head is being used in an environment where it may be in indirect contact with any food products use a food grade mineral oil on this pad. This pad will automatically apply a light amount of oil to blade and helps prevent adhesive build up on the blade, extending the blades life and performance.

Do not over oil the pad as it may become over-saturated and drip oil into the machine or onto the cases being processed. Too much oil may also negatively affect the adhesion of the tape on the cartons.

Recommended Frequency: Once per week.




Figure 18: Oiler Pad

Cleaning and Changing the Blade



WARNING: THE KNIFE CONTAINED IN THE TAPE HEADS IS EXTREMELY SHARP. EVEN A DULL BLADE CAN BE SHARP ENOUGH TO CUT. USE OF CUT RESISTANT GLOVES IS REQUIRED.

The ET xtreme tape head contains a serrated blade secured to the knife arm with two screws and is behind a red safety cover. Over time the blade may have adhesive build up, become dull, or damaged.

When cleaning the blade it is recommended to remove it from the tape head to reduce the risk of injury.

To remove the blade lift the blade safety cover. Using an Allen wrench, loosen the two screws that secure the blade. It is not necessary to completely remove the screws, the blade is slotted for easy removal and installation.

When cleaning the blade place it flat on a surface and use a mild detergent (soap and water) to clean both sides of the blade. Keep fingers away from the sharp edges of the blade.

To replace the blade slide it up until the slots are fully seated around the screws and cannot be moved any higher. Tighten the two screws down securing the blade.

Recommended Frequency: Cleaning once per week.




Figure 19: Knife Blade Change

PREVENTATIVE MAINTENANCE

Cleaning and Changing the Front Application Roller

The front urethane application roller will wear overtime as it makes contact with every carton that passes through. The roller may be cleaned with a mild detergent (soap and water). Do not use any solvent or industrial cleaners on the roller.

To remove the roller for cleaning remove the two M6 screws Two Allen wrenches will be necessary.

Use caution when removing the roller as there are washers and disc spring on the sides of the roller that may fall free. A spring and two PTFE washers can be removed from a recess in the roller core. Clean the roller thoroughly and replace it if it is damaged. Clean the shaft before replacing the urethane roller.

The urethane roller is secured to roller core by friction fitment. To remove the urethane roller from the core pull it off in the direction opposite of the flange on the roller core.

To install a new urethane roller press it onto the roller core until the urethane is firmly pressed against the flange of the roller core.

When reassembling the roller be sure to replace the disc spring and washers are in the correct order and orientation. When replacing the retaining ring be careful to not stretch out the ring. If needed replace it with a new one.

Do not use any knives or any other cutting instrument against the roller.




Figure 20: Front Roller Disassembly

Recommended Frequency: Cleaning once per week.

PREVENTATIVE MAINTENANCE

Cleaning and Changing the Rear Application Roller

The rear urethane “wobble” application roller will wear overtime as it makes contact with every carton that passes through. The roller may be cleaned with a mild detergent (soap and water). Do not use any solvent or industrial cleaners on the roller.

To remove the roller for cleaning remove the two M6 screws Two Allen wrenches will be necessary.

Clean the roller thoroughly and replace it if it is damaged. The shaft will remain in the roller as the bearing sits in a pocket. If the roller is damaged replace it.

Using two 12mm box wrenches unscrew the shaft from the central core. The other side can be pulled free from the bearing in the center of the roller. Clean this shaft. The bearing will need to be pressed out of the urethane roller. If it is damaged replace the bearing with a new one. It will need to be pressed into the new roller until it “pops” into the molded space in the center of the roller.

Insert the spacer and shaft into the fully seated bearing. Screw the other side of the shaft into the spacer. Using two 12mm box wrenches tighten the two shafts.

Do not use any knives or any other cutting instrument against the roller.




Figure 21: Rear Roller Disassembly


Recommended Frequency: Cleaning once per week.

PREVENTATIVE MAINTENANCE

Replacing the Dual Independent Wiping Tabs

The patented dual independent wipe tabs (US-20240326347-A1) assist in wiping down the top center seam of the case. While the blue wipe down rollers perform much of the wipe down, the wipe down tabs enhances the wipe down as it can better conform to the irregularities of the top of the case such as over fills, void fills and the “wash-board” effect of thinner walled corrugated.

Over time, the tabs can become distorted or worn and they should be replaced.



Remove the two screws, nuts, and rectangular washer that secures the dual tabs to the rear roller arm.

New dual independent wiping tabs have a sticker to hold them together to assist in installation.

Place the screws into the rectangular washer and feed them through the dual wiping tabs. The rectangular spring will fit into the hooked part of the tabs.

Secure the wiping tabs to the rear arm using the two nuts.

Remove the sticker on the tabs before installing the tape head back into the case sealer.

Figure 22: Dual Independent Wiping Tabs

Recommended Frequency: Inspect once per week, replace as necessary.

PREVENTATIVE MAINTENANCE

Replacing the Blade Guard and Guard Torsion Spring



WARNING: THE KNIFE CONTAINED IN THE TAPE HEADS IS EXTREMELY SHARP. EVEN A DULL BLADE CAN BE SHARP ENOUGH TO CUT. USE OF CUT RESISTANT GLOVES IS REQUIRED.

Over time the actuation of the knife blade guard will fatigue the torsion spring. The guard may also experience impacts that can damage the plastic housing.

It is vital to the safe operation of the ET xtreme tape head that the Blade Guard is functional and not damaged.

Prior to replacing the blade guard follow the blade removal process to help avoid injury.

To remove the blade guard remove the two M3 screws to free the shaft. With the screws and shaft removed both the blade guard and torsion spring can be easily removed. Discard the damaged material.

When replacing the torsion spring the straight legs of the spring will need to be on the backside of the blade mounting plate. The loop of the spring will need to be under the top side of the blade guard. Proper replacement of the spring is vital for proper functionality of the blade guard.

Align the blade guard and spring with the mounting holes on the knife arm and secure it with the two M3 screws. Verify the guard can actuate freely and returns to its home position quickly and fully. Compress the arm to verify the blade guard actuates properly against the magnet on the post.

Once proper functionality has been verified follow the blade replacement process.




Figure 23: Removing Tape Guard Rod




Figure 24: Removing Guard and Spring

Recommended Frequency: Inspect once per week, replace as necessary.

PREVENTATIVE MAINTENANCE

Replacing the Knife Guard Spring

Over time the knife arm spring can fatigue and weaken or break and need to be replaced. The knife arm spring is located at the front of the tape head and is attached to a support rod and post on the knife arm.

To replace the knife arm spring remove the retaining ring on the knife arm post. This will allow the spring assembly to slide off of the post. The spring assembly can be rotated on the shaft for easier access. Remove the plastic housing to expose the spring. The spring can now be removed from the black spring guide.

Replace the spring with a new one (UPH7427) and slide the housing back over the black spring guide. Slide the spring back onto the knife arm post. Replace the retaining ring to secure the spring assembly position. It is recommended to use a new retaining ring (UF6301) as it can be easy to damage the ring.




Figure 25: Replacing Knife Arm Spring

Recommended Frequency: Inspect once per week, replace as necessary.

PREVENTATIVE MAINTENANCE

Cleaning the Tape Path

The rollers of the tape head should be cleaned on a regular basis to keep proper functionality and smooth operation. If a tape jam occurs or the tape has been threaded incorrectly adhesive may buildup in and on the rollers. When cleaning use a mild detergent (soap and water). Do not use any industrial solvent cleaners.

Cleaning the Clutch Roller Assembly

When cleaning the rollers on the clutch assembly it may be necessary to shift or rotate the assembly to remove the lower idle roller.

Remove the retaining ring from the idle roller it will have a washer behind it. With the retaining ring removed the idle rollers can be pulled free from the shafts. Clean this rollers with a mild detergent (soap and water).

If possible when cleaning the clutch roller clean it in place with a mild detergent (soap and water). This will help keep the proper rotational resistance on the clutch roller.

If removal of the clutch roller is necessary use caution to remember the order of the washers and disk spring as they will need to be reassembled in the same order.

Remove the 10mm nut securing the clutch roller. This will allow the clutch roller to pull freely from the shaft. The disk spring and the washer can fall free of the clutch roller. Clean the clutch roller, disk spring and washers with a mild detergent (soap and water). If the one way bearings are seized the whole clutch roller will need to be replaced (UAH0283).

Replace the clutch roller on the shaft. Verify it is in the correct orientation as the one way bearings restrict rotation in one direction. Replace the washer and disk springs before securing the nut on the end of the shaft. Be sure the disc springs are in the correct orientation. When tightening the nut be sure not to over tighten or keep it too loose. The clutch roller should rotate counterclockwise when viewed from the threaded end of the shaft. It should rotate with some resistance.

Replace the idle rollers on the shafts and secure them with the retaining rings. It may be beneficial to replace the retaining rings with new ones (UF7017) as they can be easily damaged in the removal process.




Figure 26: Removal and Disassembly of the Clutch Rollers

Recommended Frequency: Clean once per week.

PREVENTATIVE MAINTENANCE

Replacing Mandrel Sprags

Over time the sprags will wear down. The red hooked sprag is essential in keeping the tape centered on the mandrel. The black sprags help keep even pressure and should be replaced at the same time as the red one.

The sprags are secured by a self tapping screw accessible from the back side of the mandrel. Use a #2 Philips screwdriver to remove the screw. Place it in a safe place nearby as they can be reused.

Once removed the sprag can be slowly pulled out from the front of the mandrel. Use caution as the sprags maintain their tension with springs that are located in predetermined seated positions on the bottom of the sprag. 2 in. tape heads will have two (2) springs while 3 in. tape heads will have three (3). Keep these springs in a safe location with the screws as they can also be reused.

Discard the worn sprag. Repeat this process for the other two (2) sprags.

When installing a new sprag it is recommended to do so when its location in the mandrel is positioned at the bottom.

Insert the new sprag so the end with the ramp is facing away from the mandrel. When the inserted sprag gets to the round locating feature, insert a spring. Compress the spring and push the sprag in to the mandrel until the next locating feature. If you are replacing a 3 in. tape head sprag a third spring will be used.

Push the sprag all the way to the back of the mandrel. Secure it with one of the self tapping screws. Repeat this process for the other two (2) sprags. Be sure at least of them is the red hooked sprag.




Figure 27: Sprag Removal

Keeping proper tension and replacing worn sprags will ensure proper grip and peel off of tape from the roll resulting in more consistent tape application.

Recommended Frequency: Inspect once per week, replace as necessary.

PREVENTATIVE MAINTENANCE

Recommended Spare Parts



WARNING: TURN OFF ELECTRICAL POWER SUPPLY AND PNEUMATIC SUPPLY (WHEN APPLICABLE) BEFORE PERFORMING MAINTENANCE. THE CUT-OFF BLADE IS EXTREMELY SHARP USE CUT RESISTANT GLOVES WHEN REPLACING THE BLADE.

ET xtreme 2" Tape Head Serial Starting With H230

UH1010 Spare Parts Kit		
Description	Item Number	QTY
Front Roller	UPH1448	1
Independent Wiper Tabs 2"	UPH4894	1
Main Spring Light	UPH0910	1
Main Spring Heavy	UPH1091	1
Cut-Off Blade 2"	UPH0193	1
Knife Guard Spring	UPH7009	1

ET xtreme 3" Tape Head Serial Starting With H430

UH1011 Spare Parts Kit		
Description	Item Number	QTY
Front Roller	UPH1449	1
Independent Wiper Tabs 3"	UPH4895	1
Main Spring Light	UPH0910	1
Main Spring Heavy	UPH1091	1
Cut-Off Blade 3"	UPH0271	1
Knife Guard Spring	UPH7009	1





Figure 28: Spare Kit Components

TROUBLESHOOTING


The ET xtreme family of tape heads have been designed with high quality components and with general preventative maintenance the head can provide many years or reliable service. Should you experience any operational difficulties that are not explained in the following section contact IPG Machinery Support at machsupp@itape.com or 803-345-3070. When contacting IPG Machinery Support please have the tape head serial number ready for the fastest possible assistance. IPG Machinery Support is available Monday - Friday, 8am - 7pm Eastern Standard Time.

Poor Tape Wipedown




IPG Machinery Support
877-447-4832 Option 4

Rear Tape Leg is Tabbing



IPG Machinery Support
877-447-4832 Option 4

Tape Does Not Cut



IPG Machinery Support
877-447-4832 Option 4

APPENDIX B

Parts Listing




Main Explosion	39
Knife Arm Assembly	40
Front Arm Assembly	41
Clutch Roller Assembly	42
Left Frame Assembly	43
Rear Arm Assembly	44
Link Arm Assembly	45
Mandrel Assembly	46
Mandrel Sub-Assembly	47
Knife Spring Assembly	48
Right Frame Assembly	49
Peel Off Arm Assembly	50
Low Tape No Tape/iTrack Sensor Kit	51

As this manual covers both 2 inch and 3 inch models of the ET xtreme each breakdown will have a column for each size of the tape head. Tape heads with serial numbers starting in H275 are 2 inch models. Tape heads with serial numbers starting in H775 are 3 inch models. Contact IPG Machinery Support at machsupp@itape.com or 813-345-3070 if you have additional questions.

Items with black balloon call outs are assemblies (made of more than one individual part).


Items with white balloon call outs are single parts.

The top right of each page with a parts breakdown will show a red highlighted section of the machine that is being broken out into more detail.



Not all assemblies are sold as assemblies please consult IPG Machine Support for details.


Commonly Ordered Assemblies



Commonly ordered assemblies			
ITEM	PART NUMBER	Description	QTY
1	UAH0223	FRONT ROLLER ASS'Y 72	1
2	UAH0222	FRONT ROLLER ASS'Y 48	1
3	UAH0208	2" TAPE SHOE ASSY	1
4	UAH0209	3" TAPE SHOE ASSY	1

APPENDIX B


Main Explosion



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	USH1122	USH1123	KNIFE ARM ASSEMBLY	1
2	USH1120	USH1119	FRONT ARM ASSY	1
3	USH1124	USH1125	CLUTCH ASSEMBLY	1
4	USH1118	USH1114	COVER FRAME ASSY	1
5	USH1121	USH1103	REAR ARM ASSEMBLY	1
6	UPH1424	UPH1314	SAFETY COVER 2"	1
7	USH4133	USH4133	LINK ASSEMBLY	1
8	USH1126	USH1127	MANDREL ASSEMBLY	1
9	USH1129	USH1129	REPULSIVE PIVOT ASSY	1
10	USH1178	USH1179	MAIN FRAME ASSY	1
11	USH1111	USH1112	PEEL-OFF ASSEMBLY	1

APPENDIX B


Knife Arm Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UAH0176	UPH1371	KNIFE ARM WITH BUSHINGS	1
2	UPH4930	UPH4930	KNIFE ARM EXTENSION	1
3	UF7008	UF7008	BHCS M4-0.7 x 6mm	6
4	UPH0193	UPH0271	BLADE	1
5	UAH0206	UAH0207	KNIFE GUARD	1
6	UF3276	UF3276	BHCS M5-0.8 x 6mm	2
7	UPH7009	UPH7009	TORSION SPRING	1
8	UPH9175	UPH9178	SHAFT, BLADE GUARD	1
9	UF6350	UF6350	FHCS M3-0.5 x 8 mm	2
10	UPH4931	UPH4931	KNIFE ARM EXTENSION	1
11	UF3557	UF3557	RETAINING RING	1

APPENDIX B

Front Arm Assembly




ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UF6402	UF6402	FW PTFE	3
2	UPH8143	UPH8143	SPRING	1
3	UPH1439	UPH1440	ROLLER CORE	1
4	UPH1448	UPH1449	ROLLER SHELL	1
5	UPH1444	UPH1443	SHAFT, 12mm DIA.	1
6	UF4401	UF4401	DISC SPRING	1
7	UF6335	UF6335	FW PTFE	2
8	UF6350	UF6350	FHCS M3-0.5 x 8 mm	1
9	UPH1438	UPH1438	STIFFENER BLOCK	1
10	UF5608	UF5608	WASHER PTFE	2
11	UPH1447	UPH1446	SHAFT 8 mm Dia.	1
12	UPH1434	UPH1435	TAPE SHOE	1
13	UPH7010	UPH7010	COMPRESSION SPRING	1
14	UPH1510	UPH1510	FINGER	1

ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
15	UF9170	UF9170	FHCS M3-0.5 x 12mm	2
16	UF6425	UF6425	SS FHCS M3-0.5 x 30MM	1
17	UPH1473	UPH1473	SLEEVE TUBING	1
18	UPH4890	UPH4890	COMPRESSION SPRING	1
19	UPH1436	UPH1436	LIMIT BLOCK	1
20	UPH4926	UPH4926	COMPRESSION SPRING	1
21	UPH1442	UPH1441	SHAFT, 10mm Dia.	1
22	UPH4924	UPH4925	GUIDE ROLLER	2
23	UPH1430	UPH1431	FRONT ARM	1
24	UF3282	UF3282	FHCS M5-0.8 x 12mm	2
25	UF3761	UF3761	FHCS M4-0.7 x 12mm	2
26	UF3261	UF3261	FHCS M6-1 x 16mm	2
27	UF4511	UF4511	RETAINING RING 8 mm	1

APPENDIX B


Clutch Roller Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UF5399	UF5399	FHCS M5-0.8 x 25mm	1
2	UPH1391	UPH1391	CLUTCH BRACKET	1
3	UPH1455	UPH1452	SHAFT, 10mm	1
4	UF6389	UF6389	NYLON WASHER METRIC	1
5	UPH1453	UPH1452	GUIDE ROLLER	1
6	UF6388	UF6388	NYLON FLAT WASHER	1
7	UF3557	UF3557	RETAINING RING 10mm	1
8	UF3404	UF3404	M6-1.0 LOCK NUT	1
9	UF3401	UF3401	NYLON WASHER	2
10	UPH8230	UPH8230	DISC SPRING	1
11	UAH0212	UAH0213	CLUTCH ROLLER	1
12	UF6402	UF6402	FW PTFE	3
13	UPH7077	UPH7078	CLUTCH SHAFT	1
14	UF3275	UF3275	FHCS M6-1 x 25mm	1
15	UF3261	UF3261	FHCS M6-1 x 16mm	1
16	UF6353	UF6353	FHCS M6-1 x 12mm	1

APPENDIX B


Left Frame Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UPH1017	UPH1017	STOP RETAINER ETM	1
2	UPH1515	UPH1515	URETHANE STOP	1
3	UPH1365	UPH1365	COVER FRAME	1
4	UF3282	UF3282	FHCS M5-0.8 x 12mm	1
5	UF3277	UF3277	FHCS M5-0.8 x 16mm	9
6	UF9170	UF9170	FHCS M3-0.5 x 12mm	2
7	UF7012	UF7012	FHCS M5-0.8 x 8mm	2
8	UPH4041	UPH1368	SPACER BAR	1
9	UPH3908	UPH3909	RETAINER, MAIN SPRING	1
10	UPH0863	UPH0863	MAIN SPRING RETAINER SLEEVE	1
11	UF3556	UF3556	RETAINING RING 9mm	1
12	UPH4886	UPH4886	SPACER WASHER	1
13	UPH133	UPH133	URETHANE STOP	1
14	UPH1017	UPH1017	STOP RETAINER ETM	1

APPENDIX B


Rear Arm Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UPH1294	UPH1295	SHAFT, REAR ARM	2
2	UPH4803	UPH4804	REAR WIPE ROLLER	1
3	UF3791	UF3791	SS SSS M6-1.0 x 30	1
4	UPH1362	UPH1362	SHAFT 12mm Dia.	1
5	UPH4674	UPH4674	PIVOTING BEARING 12mm	1
6	UF4325	UF4325	BHCS M4-0.7 x 12mm	2
7	UPH4894	UPH4895	WIPING TAB	1
8	UPH4896	UPH4897	RECTANGULAR WASHER	1
9	UAH0175	UAH0168	REAR ARM WITH BUSHINGS	1
10	UF4511	UF4511	RETAINING RING 8mm	1
11	UF3556	UF3556	RETAINING RING 9mm	1
12	UPH0863	UPH0863	MAIN SPRING RETAINER SLEEVE	1
13	UPH9248	UPH9249	RETAINER	1
14	UF7006	UF7006	M4 HEX NUT	2
15	UF3273	UF3273	FHCS M6-1 x 20mm	1
16	UF3261	UF3261	FHCS M6-1 x 16mm	2

APPENDIX B


Link Arm Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UPH4889	UPH4889	ROD END BEARING	2
2	UF3735	UF3735	M8 NUT	2
3	UPH4802	UPH4802	LINK ROD	1
4	UPH4801	UPH4801	ROD EYE SUPPORT	1
5	UF6337	UF6337	FW PTFE	1

APPENDIX B


Mandrel Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UF5904	UF5904	FHCS M5-0.8 x 20mm	4
2	UF3282	UF3282	FHCS M5-0.8 x 12mm	2
3	UPH4808	UPH4808	MANDREL ARM	1
4	UF4512	UF4512	M8 LOCKNUT	1
5	UPH4800	UPH4800	ADJUSTMENT SLEEVE	1
6	UPH7689	UPH7689	NYLON SPACER	1
7	UPH1006	UPH1006	FRICTION WASHER	1
8	UF7028	UF7028	NYLON WASHER	1
9	UAH0178	UAH0179	MANDREL ASSEMBLY	1
10	UF6335	UF6335	FW PTFE	1
11	UPH7687	UPH7688	MANDREL SHAFT	1
12	UPH1459	UPH1459	MANDREL HUB	1
13	UPH7004	UPH7004	HEX SOCKET PLUG	1

APPENDIX B


Mandrel Sub-Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY 2"	QTY 3"
1	UF3820	UF3820	SS M3 x 15 SELF TAPPING	3	3
2	UPH1383	UPH1384	HOOKED SPRAG	1	1
3	UPH1468	UPH1468	MANDREL SPRAG SPRING	6	9
4	UPH1392	UPH1393	SPRAG	2	2

APPENDIX B


Knife Spring Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UAH0151	UAH0151	SPRING MANDREL ASSY	1
2	UF3391	UF3391	M6 LOCKNUT	1
3	UF6390	UF6390	FW 6 x 16 x 1	1
4	UPH7678	UPH7678	SPRING GUIDE	1
5	UPH7427	UPH7427	COMPRESSION SPRING	1
6	UPH8123	UPH8123	SPRING BARREL V2	1

APPENDIX B


Right Frame Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UF3277	UF3277	FHCS M5-0.8 x 16mm	8
2	UF3282	UF3282	FHCS M5-0.8 x 12mm	1
3	UPH1313	UPH1313	MAIN FRAME	1
4	UF6336	UF6336	FW PTFE	2
5	UPH1422	UPH1364	SHAFT 12mm DIA.	2
6	UPH1515	UPH1515	URETHANE STOP	1
7	UPH1017	UPH1017	STOP RETAINER ETM	3
8	UAH0257	UAH0258	MAGNET ASSY	1
9	UPH1423	UPH1416	SHAFT 12mm DIA.	1
10	UF7017	UF7017	RETAINING RING	1
11	UPH133	UPH133	URETHANE STOP	2
12	UPH4886	UPH4886	SPACER WASHER	1
13	UPH3856	UPH3856	FLAT WASHER	1
14	UPH1387	UPH1363	SHAFT 10mm DIA.	1
15	UF6335	UF6335	FW PTFE	2
16	UPH4040	UPH1367	SPACER BAR	2
17	UF7012	UF7012	FHCS M5-0.8 x 8mm	2
18	UF9170	UF9170	FHCS M3-0.5 x 12mm	2

APPENDIX B


Peel Off Arm Assembly



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UF7018	UF7018	RETAINING RING 16mm	1
2	UPH1351	UPH1353	PEEL-OFF ROLLER SHAFT	1
3	UPH1354	UPH1355	PEEL ROLLER	1
4	UPH1379	UPH1379	SPACER RING	1
5	UF3283	UF3283	BHCS M5-0.8 X 10mm	2
6	UPH1350	UPH1350	PEEL-OFF BLOCK	1
7	UF3781	UF3781	FHCS M6 - 1 x 30mm	1
8	UPH1349	UPH1349	PEEL-OFF SLIDING ROD	2
9	UPH1361	UPH1361	TORSION SPRING	1
10	UPH1348	UPH1348	PEEL OFF ARM	1
11	UF7021	UF7021	LW M5	1
12	UF9173	UF9173	C-RINGS	4
13	UF3169	UF3169	SHCS M5-0.8 x 16mm	1
14	UPH1358	UPH1358	COMPRESSION SPRING	2
15	UF6340	UF6340	FW M5	2
16	UF7011	UF7011	BHCS M5-0.8 x 12mm	2
17	UPH1346	UPH1347	PEEL-OFF BASE	1
18	UPH1352	UPH1352	FRICTION WASHER	1
19	UF6403	UF6403	NYLON FLAT WASHER	1
20	UF3277	UF3277	FHCS M5-0.8 x 16mm	1

APPENDIX B

Low Tape No Tape/iTrack Sensor Kit



ITEM	PART NUMBER 2"	PART NUMBER 3"	DESCRIPTION	QTY
1	UPM7200	UPM7200	SHCS M1.6-0.35mm	2
2	UPH1741	UPH1741	NO TAPE HARNES ETX	1
3	UF6350	UF6350	FHCS M3-0.5 x 8mm	2
4	UPH1742	UPH1742	TAPE HEAD BOARD	1
5	UPH1738	UPH1739	BOARD PLATE	1
6	UF4518	UF4518	BHCS M3-0.5 x 6mm	3
7	UPH1740	UPH1740	BOX DETECT HARNES ETX	1
8	UPH1743	UPH1743	BOX DETECT BRACKET ETX	1
9	UPH1701	UPH1701	LOW TAPE HARNES ETX	1

