



SHEATHING TAPE

INSTALLATION GUIDELINES

The CCMC's compliance opinion is bound by this product being used in accordance with the conditions and limitations set out below.

- The products are permitted for taping butt joints in Tyvek® HomeWrap® Breather Type Sheathing Membrane (see CCMC 12808-R), Tyvek® HomeWrap®- Air Barrier Material (see CCMC 12857-R), Tuck® NovaWrap™ (see CCMC 13292-R), and Tuck® Novawrap™- Air Barrier Material (see CCMC 13329-R). The products are also permitted for use in new and existing residential construction, subject to the following conditions:
 - the tape can be applied at temperatures as low as -10°C, but adhesion will increase with warmer temperatures; and
 - the product shelf life is one year from the date of receipt by the retailer when stored under optimum conditions of 21°C and 50% relative humidity.
- The product must be installed in accordance with the manufacturer's current instructions, which include the following recommendations:
 - the surface to which the tape is applied should be dry and free of oil and other contamination; and
 - to ensure satisfactory adhesion, the tape should be firmly pressed down onto the substrate after application.
- The product must be clearly identified with the phrase "CCMC 11955-R".

The product must be clearly identified with the phrase "CCMC 11955-R". Application: Apply the sheathing tape using a squeegee or roller to apply firm pressure in upward and downward motion, making sure to smooth out any wrinkles or gaps. This step is critical to create the permanent bond between the housewrap and the tape.

Warranty will not be voided if a squeegee is not used, but firm pressure must be applied during installation.

The sheathing tape should be evenly distributed on either side of the housewrap. For instance, if using a 48MM roll of sheathing tape, there should be 24MM on either side of the seam.

